Luna Nanotech

PuroAE™ Plasmid MAXIprep Kit

Product Manual

#NKAE113-2	2 preps
#NKAE113-10	10 preps
#NKAE113-30	30 preps

Manual Version 1.0
September 2026

Luna Nanotech Inc.
85 Citizen Court, Unit 13
Markham, ON, Canada
L6G 1A8

Email: support@lunanano.com
Phone: 1-800-474-4055
Web: www.lunanano.com

Table of Contents

Kit Description 3

Kit Contents 3

Storage 4

Additional Materials and Equipment Required 4

Important Notes 4

Growth of Bacterial Cultures 5

Culture Volume for High-Copy Plasmids 6

Culture Volume for Low-Copy Plasmids 7

Cell Lysis 8

Protocol for High-Copy Plasmid Purification 9

Protocol for High-Copy Plasmid Purification 12

Troubleshooting 15

User Notes 19

Safety 20

Kit Description

The **PuroAE™ Plasmid MAXIprep Kit** offers a straightforward, easy-to-use workflow for the large-scale extraction and purification of plasmid DNA. Purification relies on the binding of plasmid DNA to an anion-exchange membrane, which efficiently separates it from genomic DNA, protein, salt, and other contaminants. Compared with traditional nucleic acid purification methods such as phenol-chloroform extraction, anion-exchange columns provide a simpler and safer alternative.

Together with the optimized PuroAE™ buffer formulations, this workflow yields highly purified plasmid DNA suitable for demanding downstream applications, including transfection, enzymatic digestion, and PCR.

Kit Contents

Component	2 Preps (#NKAE113-2)	10 Preps (#NKAE113-10)	30 Preps (#NKAE113-30)
Lysis Buffer LB-AE1	40mL	225 mL	450 mL
Lysis Buffer LB-AE2	40 mL	225 mL	450 mL
Neutralization Buffer NB-AE	40 mL	225 mL	450 mL
Equilibration Buffer EB-AE	40 mL	160 mL	470 mL
Wash Buffer WB-AE	80 mL	2 x 400 mL	4 x 500 mL
Elution Buffer EB-AE	40 mL	180 mL	480 mL
RNase A (20 mg/mL), DNase-free	1.6 mL	9.0 mL	18.0 mL
PuroAE™ Anion-Exchange Columns	2	10	30

Storage

RNase A should be stored at -20 °C. All components can be stored at room temperature for at least 1 year. Once **RNase A** is added to **Lysis Buffer LB-AE1**, the buffer should be stored at 4 °C.

Additional Materials and Equipment Required

- 70% Ethanol
- 100% Isopropanol
- 50 mL RNase-free centrifuge tubes
- Buffer for reconstitution of DNA: TE buffer or sterile H2O
- Pipettes and sterile nuclease-free pipette tips
- Refrigerated centrifuge (with ≥ 16,000 x g or ≥ 5,000 x g capability)
- Vortex (if not available, can be replaced with vigorous pipetting)
- Appropriate personal protective equipment (gloves, lab coat)

Important Notes

BEFORE USE:

- Add **RNase A** (20 mg/mL) to **Lysis Buffer LB-AE1**. *After addition, store the buffer at 4 °C.*
    - **#NKAE113-2** (2 preps): add **1.6 mL** of RNase A
    - **#NKAE113-10** (10 preps): add **9.0 mL** of RNase A
    - **#NKAE113-30** (30 preps): add **18.0 mL** of RNase A

- If precipitate is observed in the **Lysis Buffer LB-AE2**, re-dissolve it by warming the solution to 37 °C. Cool the solution back to room temperature before use.
- Pre-chill **Neutralization Buffer NB-AE** at 4 °C.

Growth of Bacterial Cultures

DNA yield and quality depend on a lot of variables: the growth medium and antibiotic used, the host strain, the plasmid's type/size/copy number, and the growth conditions themselves.

Medium and conditions: For standard high-copy plasmids, LB medium is the go-to choice, incubated at 37°C with vigorous shaking (200–250 rpm), ideally overnight for 12–16 h. Use flasks 3–4x larger than the culture volume so the medium stays well-oxygenated. Richer media like 2xYT, TB, are alternatives — bacteria grow faster and hit stationary phase much sooner (within 2 h) with these, reaching higher cell densities. But more cells doesn't automatically mean more plasmid DNA: overgrown cultures can accumulate dead or starving cells, leading to degraded plasmid DNA or contamination with genomic DNA. The ideal medium and incubation time really needs to be worked out for each specific strain/plasmid combination. Antibiotic selection: Keep cultures under antibiotic selection throughout growth to maintain the plasmid. Without that pressure, cells readily lose the plasmid during division — and since plasmid-free cells grow faster (they're not burdened with replicating it), they quickly dominate the culture, tanking plasmid yield even if total cell mass looks fine.

Host strain: This mainly affects DNA quality. Strains like DH5α or XL1-Blue give clean, supercoiled plasmid DNA, while strains with high endonuclease activity (like HB101) can degrade DNA quality, causing problems in downstream steps like restriction digests or sequencing.

Plasmid type: Size and origin of replication (ori) strongly affect yield. Bigger plasmids or inserts generally mean lower yield due to reduced copy number — even a normally high-copy ColE1-based construct can act like a low-copy plasmid if it carries a large or problematic insert. The ori itself can shift yield by 10–100x: plasmids/cosmids/BACs built on origins like pBR322 or pACYC sit at under 20 copies per cell (sometimes just 1), while pUC-, pBluescript-, or pGEM-based vectors can reach several hundred copies per cell.

Bottom line: all these factors need to be weighed together when targeting a specific DNA yield, and culture volume and lysis steps should be adjusted accordingly.

Culture Volume for High-Copy Plasmids

The amount of bacterial cells in a culture depends on many factors — the growth medium used (TB, CircleGrow, 2xYT), shaking speed, temperature, host strain, and even the plasmid insert itself. As a general guideline, a 1-liter E. coli LB culture at OD_{600} = 1 contains roughly 1 trillion cells and produces about 1.5–1.8 g of wet cell mass. Shaken overnight LB cultures typically reach OD_{600} values of 3–6, while fermenter-grown cultures can exceed OD_{600} of 10. High-copy plasmids typically yield around 1 mg of DNA per gram of wet cell mass, which is why it's better to base prep on cell mass rather than culture volume. Since weighing cell mass directly is inconvenient, the manual instead uses a calculated value called ODV (optical density x volume):

ODV = OD_{600} × Volume (mL)

If culture's OD_{600} goes above 0.5, it require to dilute it before measuring (a 1:10 dilution with fresh medium works well), then multiply the reading by the dilution factor to get the true OD_{600}. This value is then used with a reference table (**Table #1**) to figure out how much culture volume to use. For example: if the OD_{600} of *E.coli* is 2, calls for 66 mL in a Midi prep or 200 mL in a Maxi prep.

Table #1: Recommended culture volumes for high copy plasmid

Puro-AE™	Pellet Wet Weight	Recommended ODV	OD_{600} = 2	OD_{600} = 4	OD_{600} = 6	OD_{600} = 8	OD_{600} = 10
MAXI	2.25 g	1200	600 mL	300 mL	200 mL	150 mL	120 mL

Culture Volume for Low-Copy Plasmids

PuroAE™ Plasmid MAXIprep Kit can be used to purify both high-copy plasmids (up to several hundred copies per cell) and low-copy plasmids (fewer than 20 copies per cell). For low-copy plasmids, however, both the amount of cells and the volume of lysis buffer must be scaled up by a minimum of two-fold, so that enough DNA is available to make full use of the column's binding capacity.

Table #2 lists the recommended ODV values along with matching combinations of OD_{600} and culture volume for low-copy plasmid cultures. (See section "**Culture Volume for High-Copy Plasmids**" for details on how ODV is calculated, where ODV = OD_{600} × volume.) For example, an *E. coli* culture with an OD_{600} of 6 would require 400 mL for a Maxi prep.

Table #2: Recommended culture volumes for low copy plasmid

Puro-AE™	Pellet Wet Weight	Recommended ODV	OD_{600} = 2	OD_{600} = 4	OD_{600} = 6	OD_{600} = 8	OD_{600} = 10
MAXI	4.5 g	2400	1200 mL	600 mL	400 mL	300 mL	240 mL

Scaling the culture and lysis buffer volumes up even further — by a factor of 3–5, for instance — will give still better yields. Extra lysis buffer is available as a separate purchase.

Cell Lysis

The bacterial pellet is first resuspended in Lysis Buffer LB-AE1, then lysed with Lysis Buffer LB-AE2 via a sodium hydroxide/SDS treatment. These conditions denature proteins along with both chromosomal and plasmid DNA, while RNase A breaks down RNA. Adding Neutralization Buffer NB-AE — which contains potassium acetate — causes the SDS to come out of solution as potassium dodecyl sulfate (KDS), a precipitate that carries proteins, chromosomal DNA, and other cell debris down with it. At the same time, the potassium acetate neutralizes the lysate, allowing plasmid DNA to return to its native supercoiled conformation and stay dissolved.

In the standard protocol, buffer volumes are calibrated for the culture volumes listed for high-copy plasmids in section "Culture Volume for High-Copy Plasmids", Table #1. Overloading the system with cell material compromises both lysis and precipitation efficiency, which can lower plasmid yield and purity. Lysis buffer volumes therefore need to be scaled up whenever larger cultures are processed — as is the case for low-copy vector purification section "Culture Volume for Low-Copy Plasmids", Table #2.

As a rough guide, the required volumes of Lysis Buffer LB-AE1, Lysis Buffer LB-AE2, and Neutralization Buffer NB-AE can be estimated with:

Volume [mL] = Culture volume [mL] × OD_{600} ÷ 50

For example, 400 mL of a low-copy culture at OD_{600} = 2, you would use 16 mL of each of the buffers. Should the kit not contain enough buffer for your preparation, a supplementary set comprising Lysis Buffer LB-AE1, Lysis Buffer LB-AE2, Neutralization Buffer NB-AE, and RNase A can be purchased separately.
Using an adequate buffer volume keeps lysis short — 3–4 minutes is sufficient, and 5 minutes should be treated as the upper limit. Leaving the sample in alkaline conditions for longer risks irreversible denaturation and degradation of the plasmid DNA, and can release contaminating chromosomal DNA into the lysate.

Protocol for High-Copy Plasmid Purification

Step	Procedure
1	Prepare overnight bacterial culture in LB media by inoculating a single bacterial colony into 2 mL of LB media and incubating overnight. Dilute the starter culture up to 1:10,000 in fresh LB media. Incubate the culture overnight or until OD600 reaches 2 – 3.
2	Determine the OD_{600} of your culture and use it to work out the appropriate culture volume: **V [mL] = 1200 ÷ OD_{600}** Collect the cells by centrifuging at 5,000 × g for at least 10 min at 4 °C, then pour off all of the supernatant. *NOTE: Efficient lysis depends on maintaining a specific ratio between the cell mass and the volumes of Buffers LB-AE1, LB-AE2, and NB-AE. Recommendations for the optimal pelleted culture volume are given in section, "Culture Volume for High-Copy Plasmids" for cells carrying high-copy plasmids and in section, "Culture Volume for Low-Copy Plasmids for those with low-copy plasmids on page 6 of the manual* . **The buffers volumes suggested in steps below assume a final OD_{600} of the culture = 4 and culture volume of 200 mL.**
3	Add 16 mL of **Lysis Buffer LB-AE1** (*with RNase A added*) to collected pellet. Resuspend cells by vortexing. No clumps should be left behind, as these prevent efficient lysis. *NOTE: If started with more than the recommended cell mass, scale the LB-AE1 volume up accordingly. (See section "Cell Lysis" on page 7 of the manual).*
4	Add 16 mL of **Lysis Buffer LB-AE2** to the cell suspension and mix gently by inverting the tube five times. Never vortex — shearing releases contaminating chromosomal DNA from the cell debris. Incubate 5 min at room temperature. *NOTE 1: Inspect Lysis Buffer LB-AE2 for precipitated SDS before use; if white precipitate is visible, warm the buffer at 37 °C for a few minutes until it redissolves completely, then let it return to room temperature.* *NOTE 2: Scale the Lysis Buffer LB-AE2 volume proportionally for larger cell inputs (See section "Cell Lysis" on page 7 of the manual).* *NOTE 3: Extended exposure to alkali can irreversibly denature and degrade the plasmid DNA and free chromosomal DNA into the lysate. Do not exceed 5 minutes of Lysis.*

5	*Equilibrate the* **PuroAE™ Anion-Exchange Column.** *Pour 15 mL of* **Equilibration Buffer EB-AE** *onto the rim of the column, (angle the pipette tip against the inner wall of the column,* **AVOID** *dispensing the buffer directly onto the membrane surface) let the column drain by gravity. The column will not run dry.*
6	Add 16 mL of pre-chilled **Neutralization Buffer NB-AE** and mix the lysate gently by inverting the tube for 8 - 10 times, Do not vortex. *NOTE 1: Chill Buffer Neutralization Buffer NB-AE on ice or refrigerate it before use.* *NOTE 2: Complete neutralization is essential for precipitating all protein and chromosomal DNA: the lysate should change from slimy and viscous to a thin, uniform suspension containing an off-white flocculate.* *NOTE 3: Scale the Neutralization Buffer NB-AE volume proportionally for larger cell inputs (See section "Cell Lysis" on page 7 of the manual).*
7	Centrifuge at ≥20,000 x g for 30 min at 4°C (high-speed centrifuge) OR at ≥ 5,000 x g for 45 min at 4°C (low-speed centrifuge). *NOTE: If white flocculate remains suspended in the supernatant, transfer supernatant to a fresh tube and spin again (ideally faster at faster g-force)*
8	Carefully remove supernatant containing plasmid DNA and apply onto the rim of the equilibrated **PuroAE™ Anion-Exchange Column**, (angle the pipette tip against the inner wall of the column, AVOID dispensing the supernatant directly onto the membrane surface) let the column drain by gravity.
9	Wash the column by applying 30 mL of **Wash Buffer WB-AE**. Angle the pipette tip against the inner wall of the column, AVOID dispensing the buffer directly onto the membrane surface let the column drain by gravity.
10	Repeat *STEP 9* with another 30 mL of **Wash Buffer WB-AE**.
11	Add 15 mL of **Elution Buffer EB-AE** to the column. Collect the eluate in a 50 mL centrifuge tube (*not provided).* NOTE: Warming **Elution Buffer EB-AE** to 50 °C beforehand can improve yields for large constructs such as BACs.

12	Add 10.5 mL of **room-temperature isopropanol** to the eluate and vortex thoroughly. Centrifuge at ≥ 16,000 x g for 30 min at 4 °C (high-speed centrifuge) OR at 5,000 x g for 60 min at 4 °C (low-speed centrifuge). Discard the supernatant carefully.
13	Add 5 mL of **room-temperature 70 % ethanol** (*not provided*) to the pellet. Centrifuge at ≥ 16,000 × g for 10 min at 4 °C (high-speed centrifuge) OR at 5,000 x g for 60 min at 4 °C (low-speed centrifuge). Remove all the ethanol with a pipette tip and let the pellet air-dry at room temperature for 10 - 15 minutes. NOTE: Do not over-dry the plasmid DNA as it can be difficult to redissolve.
14	Redissolve the pellet in a suitable volume of TE buffer or sterile H_2O. Depending on the tube format, dissolve by gentle pipetting or by continuous rotation for 10–60 min on a 3D shaker.

Protocol for Low-Copy Plasmid Purification

The lysis buffer volumes provided in the kit are adjusted for high copy plasmid purification. Therefore, additional buffer has to be ordered separately for routine purification of low copy plasmids.

Step	Procedure
1	Prepare overnight bacterial culture in LB media by inoculating a single bacterial colony into 2 mL of LB media and incubating overnight. Dilute the starter culture up to 1:10,000 in fresh LB media. Incubate the culture overnight or until OD600 reaches 2 – 3.
2	Determine the OD_{600} of your culture and use it to work out the appropriate culture volume: **V [mL] = 2400 ÷ OD_{600}** Collect the cells by centrifuging at 5,000 × g for at least 10 min at 4 °C, then pour off all of the supernatant. *NOTE: Efficient lysis depends on maintaining a specific ratio between the cell mass and the volumes of Buffers LB-AE1, LB-AE2, and NB-AE. Recommendations for the optimal pelleted culture volume are given in section, "Culture Volume for High-Copy Plasmids" for cells carrying high-copy plasmids and in section, "Culture Volume for Low-Copy Plasmids for those with low-copy plasmids on page 6 of the manual .* **The buffers volumes suggested in steps below assume a final OD_{600} of the culture = 6 and culture volume of 400 mL.**
3	Add 48 mL of **Lysis Buffer LB-AE1** (*with RNase A added*) to collected pellet. Resuspend cells by vortexing. No clumps should be left behind, as these prevent efficient lysis. *NOTE: If started with more than the recommended cell mass, scale the LB-AE1 volume up accordingly. (See section "Cell Lysis" on page 7 of the manual).*
4	Add 48 mL of **Lysis Buffer LB-AE2** to the cell suspension and mix gently by inverting the tube five times. Never vortex — shearing releases contaminating chromosomal DNA from the cell debris. Incubate 5 min at room temperature. *NOTE 1: Inspect Lysis Buffer LB-AE2 for precipitated SDS before use; if white precipitate is visible, warm the buffer at 37 °C for a few minutes until it redissolves completely, then let it return to room temperature.*

	NOTE 2: Scale the Lysis Buffer LB-AE2 volume proportionally for larger cell inputs (See section "Cell Lysis" on page 7 of the manual). *NOTE 3: Extended exposure to alkali can irreversibly denature and degrade the plasmid DNA and free chromosomal DNA into the lysate. Do not exceed 5 minutes of Lysis.*
5	*Equilibrate the* **PuroAE™ Anion-Exchange Column.** *Pour 15 mL of* **Equilibration Buffer EB-AE** *onto the rim of the column, (angle the pipette tip against the inner wall of the column,* **AVOID** *dispensing the buffer directly onto the membrane surface) let the column drain by gravity. The column will not run dry.*
6	Add 48 mL of pre-chilled **Neutralization Buffer NB-AE** and mix the lysate gently by inverting the tube for 8 - 10 times, Do not vortex. *NOTE 1: Chill Buffer Neutralization Buffer NB-AE on ice or refrigerate it before use.* *NOTE 2: Complete neutralization is essential for precipitating all protein and chromosomal DNA: the lysate should change from slimy and viscous to a thin, uniform suspension containing an off-white flocculate.* *NOTE 3: Scale the Neutralization Buffer NB-AE volume proportionally for larger cell inputs (See section "Cell Lysis" on page 7 of the manual).*
7	Centrifuge at ≥20,000 x g for 30 min at 4°C (high-speed centrifuge) OR at ≥ 5,000 x g for 45 min at 4°C (low-speed centrifuge). *NOTE: If white flocculate remains suspended in the supernatant, transfer supernatant to a fresh tube and spin again (ideally faster at faster g-force)*
8	Carefully remove supernatant containing plasmid DNA and apply onto the rim of the equilibrated **PuroAE™ Anion-Exchange Column**, (angle the pipette tip against the inner wall of the column, AVOID dispensing the supernatant directly onto the membrane surface) let the column drain by gravity.
9	Wash the column by applying 30 mL of **Wash Buffer WB-AE**. Angle the pipette tip against the inner wall of the column, AVOID dispensing the buffer directly onto the membrane surface let the column drain by gravity.
10	Repeat *STEP 9* with another 30 mL of **Wash Buffer WB-AE**.

11	Add 15 mL of **Elution Buffer EB-AE** to the column. Collect the eluate in a 50 mL centrifuge tube (*not provided)*. NOTE: Warming **Elution Buffer EB-AE** to 50 °C beforehand can improve yields for large constructs such as BACs.
12	Add 10.5 mL of **room-temperature isopropanol** to the eluate and vortex thoroughly. Centrifuge at ≥ 16,000 x g for 30 min at 4 °C (high-speed centrifuge) OR at 5,000 x g for 60 min at 4 °C (low-speed centrifuge). Discard the supernatant carefully.
13	Add 5 mL of **room-temperature 70 % ethanol** (*not provided*) to the pellet. Centrifuge at ≥ 16,000 × g for 10 min at 4 °C (high-speed centrifuge) OR at 5,000 x g for 60 min at 4 °C (low-speed centrifuge). Remove all the ethanol with a pipette tip and let the pellet air-dry at room temperature for 10 - 15 minutes. NOTE: Do not over-dry the plasmid DNA as it can be difficult to redissolve.
14	Redissolve the pellet in a suitable volume of TE buffer or sterile H_2O. Depending on the tube format, dissolve by gentle pipetting or by continuous rotation for 10–60 min on a 3D shaker.

Troubleshooting

Problem	Possible causes and solutions
No or low plasmid DNA yield	**The plasmid failed to propagate** Before committing to a large-scale purification, gauge how much plasmid is present by running a quick PuroSPIN ™ Plasmid Miniprep Purification Kit. **Alkaline lysis was incomplete** The cell input was too high. See sections “Culture volume for High-Copy Plasmids” on Page 6 of the manual and “Culture Volume for Low-Copy Plasmids” on Page 7 of the manual for the culture and lysis buffer volumes that are recommended. Look for SDS precipitation in Lysis Buffer LB-AE2, before use — this is especially likely after storage below 20 °C. If needed, warm the bottle at 37 °C for several minutes and mix well until the SDS has fully redissolved. **SDS or other precipitates remain in the sample** After centrifugation when transferring the lysate to the column make sure no SDS precipitates are added with supernatant. Whenever precipitate is visible re-centrifuge the lysate again as indicated before loading it. **The sample or lysate is too viscous** Too much cell mass was used — consult sections “Culture volume for High-Copy Plasmids” on Page 6 of the manual and “Culture Volume for Low-Copy Plasmids” on Page 7 of the manual for appropriate culture and lysis buffer volumes. Mix thoroughly after neutralization so that SDS and chromosomal DNA precipitate fully. Otherwise, residual SDS blocks DNA from binding to the column.
PuroAE™ An-ion-Exchange Column is blocked or running very slowly	**The sample is too viscous** Never try to purify a lysate made from a culture larger than the recommendation for that column size while using standard lysis buffer volumes. Beyond blocking the column, incomplete lysis can cut yields substantially. Refer ee sections “Culture volume for High-Copy Plasmids” on Page 6 of the

	manual and “Culture Volume for Low-Copy Plasmids” on Page 7 of the manual. Mix well after neutralization to precipitate all SDS and chromosomal DNA. **The lysate was not fully cleared** Centrifuge the lysate harder or for longer. Precipitate can form during storage; re-clear the lysate before loading the column.
Genomic DNA contamination of the plasmid	**Lysis was too harsh** Do not exceed 5 min of lysis in Lysis Buffer LB-AE2. **The lysate was mixed too vigorously, or vortexed after lysis** Invert the tube exactly five times as indicated in the protocol; never vortex once Lysis Buffer LB-AE2 has been added. Switch to larger tubes, or scale the culture down, to make gentle mixing easier.
RNA contamination of the plasmid	**RNase digestion was inefficient** Either no RNase was added to Lysis Buffer LB-AE1, or it was stored incorrectly. Add fresh RNase to Lysis Buffer LB-AE1 and store at 4 °C when is not used. **Wash buffer pH or salt concentration is too low** Keep all buffers tightly closed as exposure to oxygen can effect the pH of buffers. **Washing with Wash Buffer WB-AE was insufficient** Make sure to wash the column with Wash Buffer WB-AE two times as indicated in the protocol.
Low purity (A260/A280 < 1.8)	**Only a small amount of DNA was loaded** With a lot of binding capacity left unoccupied, more thorough washing is needed — perform the wash twice as indicated. Shorten lysis to under 5 min.

No nucleic acid pellet after precipitation	**The pellet was lost** Treat the precipitate gently and decant solutions (Isopropanol and 70% Ethanol) with care. **The plasmid DNA may be smeared along the tube wall** Dissolve the DNA pellet in a suitable volume of reconstitution buffer, making sure to pipette on the side on the tube to get all DNA. **The nucleic acid did not precipitate** Confirm the identity and volume of the precipitating solvent; use at least 0.7 volumes of isopropanol and mix thoroughly. Centrifuge longer and at higher speed.
The pellet is opaque or white rather than clear and glassy	**Salt co-precipitated** Verify the purity of the isopropanol. Precipitate at room temperature but spin at 4 °C. Rather than letting the eluate drip from the column straight into isopropanol, add the isopropanol to the collected eluate and mix at once. Alternatively, resuspend the pellet in Elution Buffer EB-AE and reload it onto the same column, washing the column several times with Wash Buffer WB-AE beforehand.
The pellet will not redissolve	**It was over-dried** Dissolve the plasmid DNA pellet at an elevated temperature over a longer period — for example 2 h at 37 °C or overnight at room temperature ideally with constant rotation on a 3D shaker. **Salt or residual alcohol co-precipitated** Wash the pellet again with 70 % ethanol, or use more reconstitution buffer.
Insoluble particles in the redissolved DNA	Spin the redissolved DNA down to pellet the particles and move the supernatant to a clean tube; these particles have no effect on DNA quality.

The purified plasmid performs poorly in downstream reactions	**Chromosomal DNA or RNA is contaminating the plasmid** See the detailed troubleshooting sections above. **Residual alcohol is contaminating the plasmid** The DNA was redissolved before it had dried fully. Re-precipitate by adding 1/10 volume of 3 M sodium acetate (pH 5.0) together with 0.7 volumes of isopropanol, then follow the precipitation protocol given in this manual, this time letting the pellet dry completely. **DNA is degraded** Confirm that all equipment — pipettes, centrifuge tubes, and so on — is clean and free of nucleases. Keep lysis in Lysis Buffer LB-AE2 to no more than 5 min. **The DNA is irreversibly denatured** On a gel, denatured plasmid migrates faster than the supercoiled form. Do not leave the sample in Lysis Buffer LB-AE2 for longer than 5 min after adding it.

User Notes

Safety

Reagent	Risk Symbols	Risk and Safety Phrases
Lysis Buffer LB-AE2, Netralization Buffer NB-AE, Wash Buffer WB-AE, Elution Buffer EB-AE		Contain *Sodium Dodecyl Sulfate* and *Glacial Acetic Acid* • Harmful if swallowed. • Irritating to eyes and skin. • Do not breathe vapors and fumes • Wear suitable protective clothing and gloves. • In case of contact with eyes immediately wash with plenty of water and seek medical advice. • If swallowed, seek medical advice and contact poison control center.

This product is intended solely for research use only. Full material safety data sheet document is available at www.lunanano.com.

For further information about this and other products please visit our website at www.lunanano.com.

Learn more at lunanano.com/dna-rna-purification-products

Luna Nanotech Inc.
85 Citizen Court, Unit 13
Markham, ON, Canada
L6G 1A8

Email: support@lunanano.com
Phone: 1-800-474-4055
Web: www.lunanano.com

Luna Nanotech
Nano for Bio